



Domani Tile, Inc.
7135 Madison Ave. West
Suite 1200
Minneapolis, MN USA 55427

toll free 877.786.8300
763.544.2441
fax 763.559.0260
www.domaniitile.com
domani@domaniitile.com

INSTALLATION INSTRUCTIONS AND SPECIFICATIONS

These instructions are provided as a general guideline to cover most applications, and are written for experienced, professional tile installers. Please read these instructions before beginning any work.

- All Domani Tile installations benefit by extended cure times prior to grouting
- Use non-sanded grout or clear silicone as a grouting substance
- Domani Tiles, Table Tops & Vanity Tops are to be installed exclusively indoors

WALLS & BACKSPLASHES

1. Domani Tiles have a durable **acrylic backing** material that may not be compatible with standard tile mastics and adhesives. Therefore, we recommend using a non-solvent based adhesive, like **Bostik 70-03A**. Please refer to our website for the Bulletin and Material Safety Data pdf.
2. Apply the adhesive directly to the back of each tile and apply to a fully cured wall surface. To prevent slippage during installation, you may want to create an 8 point masking tape support assembly which consists of a cross vertically and horizontally with an X across the tape.
3. Remove the masking tape after 24 hours and grout accordingly.

GLASS TILE CUTTING INSTRUCTIONS

- Using a Rubi Cutter with a 6mm wheel, score the backside of the tile
- With a sharp utility knife, cut through the backer along the score line
- Turn tile over & **GENTLY** score the glass with the same wheel & **snap**
- Once glass & backer are cut, turn tile over (face down) & cut adhesive layer in between the backer and the glass
- Polish the top glass edge along the score line with #100-800 Granite Stone polishing pads at an angle to remove sharp edges
- **ALWAYS USE EYE PROTECTION** when working with glass tiles